



安装说明书

LD-2002 跪式弯举








项目号	代号	名称	数量
1	R20-9741	左侧架	1
2	R20-9743	前横撑	1
3	R20-9744	纵撑	1
4	R20-9742	右侧架	1
5	R04-9899	撑	1
6	M12花垫	M12花垫	20
7	M12平垫圈	M12平垫圈	20
8	M12弹垫	M12弹垫	20
9	M12防松帽	M12防松帽	20
10	R02-1774	55补强垫	16
11	M12X75圆柱头	M12X75圆柱头	16
12	M12X110圆柱头	M12X110圆柱头	4
13	R20-9747	中撑	1
14	“图样代号”	“图样名称”	1

安装1

项目号	代号	名称	规格	数量
1	LD-2002	安装1		1
2	R20-9748	跪垫架		1
3	M12花垫	M12花垫		1
4	M12平垫圈	M12平垫圈		1
5	M12弹垫	M12弹垫		1
6	M12防松帽	M12防松帽		1
7	M12X135圆柱头	圆柱头M12X135		1





安装2



局部视图 A
比例 1 : 10



项目号	代号	名称	数量
1	LD-2002	安装3	1
2	R320-9745	右力臂	2
3	R20-9749	右摆臂	1
4	R08-1024	52孔装饰盖	1
5	M5x6顶丝	M5x6顶丝	4
6	52加深装饰盖装配		2
7	R03-9797	M8关节垫片	4
8	M8弹垫	M8弹垫	4
9	M8X16圆柱头	M8X16圆柱头	4
10	R20-9750	拉杆组	2
11	R20-9746	左摆臂	1
12	R08-1024	60铝盖	1

安装3







项目号	代号	名称	规格	数量
1	LD-2002	安装3		1
2	R20-9754	胸垫调节纵撑		1
3	M12平垫圈	M12平垫圈		4
4	M12弹垫	M12弹垫		2
5	M12防松帽	M12防松帽		2
6	M12X80圆柱头	M12X80圆柱头		2

安装4



项目号	代号	名称	数量
1	LD-2001	安装5	1
2	R20-1026	HS-1030跪式弯举肘垫带塑料壳	1
3	R20-1028	HS-1030跪式弯举膝垫带塑料壳	2
4	R20-1027	HS-1030跪式弯举腹垫带塑料壳	2
5	R20-9678	200杠铃套 3°	2
6	R02-9738	示意板80°	1
7	M8弹垫	M8弹垫	2
8	M8X16圆柱头	M8X16圆柱头	2
9	M8平面垫圈	M8平面垫圈	2
10	M10平面垫圈	M10平面垫圈	10
11	M10弹垫	M10弹垫	10
12	M10×35圆柱头	M10×35圆柱头	6
13	M10×70	圆柱头M10×70	4
14	R02-1774	55补强垫	4
15	M12花垫	M12花垫	4
16	M12X75圆柱头	M12X75圆柱头	4
17	M12平垫圈	M12平垫圈	4
18	M12弹垫	M12弹垫	4
19	M12防松帽	M12防松帽	4



项目号	代号	名称	数量
1	LD-2001	安装4	1
2	R20-1026	HS-1030跪式弯举肘垫带塑料壳	1
3	R20-1028	HS-1030跪式弯举膝垫带塑料壳	2
4	R20-1027	HS-1030跪式弯举腹垫带塑料壳	2
5	R20-9678	200杠铃套 3°	2
6	R02-9738	示意板80°	1
7	M8弹垫	M8弹垫	2
8	M8X16圆柱头	M8X16圆柱头	2
9	M8平面垫圈	M8平面垫圈	2
10	M10平面垫圈	M10平面垫圈	10
11	M10弹垫	M10弹垫	10
12	M10×35圆柱头	M10×35圆柱头	6
13	M10×70	圆柱头M10×70	4
14	R02-1774	55补强垫	4
15	M12花垫	M12花垫	4
16	M12X75圆柱头	M12X75圆柱头	4
17	M12平垫圈	M12平垫圈	4
18	M12弹垫	M12弹垫	4
19	M12防松帽	M12防松帽	4

安装5-2